

PUTCO™

GRILLE INSERT INSTALLATION SHEET

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance please feel free to call us at: 1-800-247-3974 Monday-Friday 8:00 a.m. – 5:00 p.m. (C.S.T.) Contact your Putco dealer for other quality accessories.

Putco Inc. – 216 W. 1st Street – Story City, IA 50248

PLEASE READ ALL INSTRUCTIONS BEFORE INSTALLATION AND TO CHECK TO SEE THAT ALL PARTS ARE INCLUDED.

Please consult your Vehicles owner's manual for vehicle air flow restrictions.

Putco is not liable for any vehicle damage resulting from the installation of our Grille inserts.

2002-UP CHEVROLET AVALANCHE, 99-UP CHEVROLET SILVERADO/SUBURBAN, 2001-UP CHEVROLET HEAVY DUTY, 99-UP GMC SIERRA/YUKON, 2001-UP GMC HEAVY DUTY, 99-UP FORD F-SERIES LIGHT DUTY, 2003 CHEVROLET HEAVY AND LIGHT DUTY, 2003 GMC HEAVY AND LIGHT DUTY

- Step 1: Remove the factory plastic hood that covers the area between the grille and radiator by removing the plastic plugs or screws that fasten it in place.
- Step 2: Remove the bolts and mounting plates for the bag kit.
- Step 3: Place the grille insert over the grille, making sure that it is centered on the vehicle.
- Step 4: Reach between the grille and radiator and reinstall the bolts, plates and nuts onto the grille insert.
- Step 5: Check to make sure the grille is properly in place and tighten the bolts just enough to hold the grille in place.
- DO NOT OVER TIGHTEN as this may cause the grille to crack.

99-UP FORD SUPER DUTY PICKUP AND EXCURSION, HORIZONTAL SIDE VENTS

- Step 1: Remove the four factory screws that hold the top of the factory grille in place.
- Step 2: Remove the bolts and mounting plates from the bag kit.
- Step 4: Place the grille insert over the grille making sure that it is centered on the vehicle. If you have purchased the side vent pieces install them at this time. NOTE: The installation bolt will go through a hole in the side vent that is closest to the center grille section.
- Step 5: Carefully pull the grille forward and reach between the grille and radiator, install the bolts and mounting brackets onto the grille insert and/or the flat washer and nut on the side vent pieces.
- Step 6: Check to make sure that grille is properly in place and tighten the bolts just enough to hold the grille in place. DO NOT OVER TIGHTEN as this may cause the grille to crack.

94-UP DODGE RAM

- Step 1: Remove the bolts and mounting plates from the bag kit.
- Step 2: Place the grille insert over the grille making sure that it is centered on the vehicle.
- Step 3: Reinstall the plates and nuts onto the grille insert.
- Step 4: Check to make sure the grille is properly in place and tighten the bolts just enough to hold the grille in place. DO NOT OVER TIGHTEN as this may cause the grille to crack.

Note: Please adjust horizontal blades if irregular. This is the result of shipping and handling outside of Putco's control.

Note: Putco recommends applying a high quality automotive wax to maintain the original appearance.

LIMITED WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90-day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.